



Venture Lighting Hyskeir Highbay


Installation Instructions and Conditions of Use

IMPORTANT INFORMATION


- Please understand the following instructions and installation procedure before proceeding. Work should be carried out by a qualified electrician.
- The standard warranty offered with these LED products as displayed at www.venturelightingeurope.com/technical-centre/warranty can only be upheld providing the following instructions and conditions of use are strictly adhered to. Venture Lighting will not be held responsible for any claims resulting from inadequate installation and therefore advice may be required from a qualified person before proceeding.
- This product cannot be serviced; there are no serviceable parts inside and the product should not be opened unless instructed below to enable electrical connection / or mechanical fixing.
- The LEDs in the luminaire are not replaceable and the casing should not be opened. When the LEDs reach end of life the whole luminaire shall be replaced.
- The external flexible cable of these luminaires cannot be replaced. If the cable is damaged the luminaire shall be destroyed.

Installation Instructions:

Suspension Mounting



Surface Mounting



Dimming Operation

The luminaire is dimmable to 10% of rated power by either of the following methods:


- Resistor Method - Referring to the below table connect the appropriate resistor between DIM+ and DIM -

Resistor Value	10KΩ	20KΩ	30KΩ	40KΩ	50KΩ	60KΩ	70KΩ	80KΩ	90KΩ	100KΩ	Open
Power	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%	100%

- 1-10V Dimming Input - Referring to the below table supply a 1-10V dimming signal to DIM+ and DIM -

Input Volts	1V	2V	3V	4V	5V	6V	7V	8V	9V	10V	Open
Power	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%	100%

Wiring Connections



Disconnect DIM+ and DIM- for full power operation.



Document Revision 3 03/11/2018