



Venture Lighting Non-Corrosive Luminaires Installation Instructions and Conditions of Use

IMPORTANT INFORMATION

- Please understand the following instructions and installation procedure before proceeding. Work should be carried out by a qualified electrician.
- The standard warranty offered with these LED products as displayed at www.venturelightingeurope.com/technical-centre/warranty can only be upheld providing the following instructions and conditions of use are strictly adhered to. Venture Lighting will not be held responsible for any claims resulting from inadequate installation and therefore advice may be required from a qualified person before proceeding.
- This product cannot be serviced; there are no serviceable parts inside and the product should not be opened unless instructed below to enable electrical connection / or mechanical fixing.
- The LEDs in the luminaire are not replaceable. When the LEDs reach end of life the whole luminaire shall be replaced.


Installation Instructions

Product can be surface or suspension mounted using stainless steel clips provided.

For surface mounting use fixings provided and follow diagram below.

Fixing dimensions "A" are 900mm for 4ft NCRs, 1200mm for 5ft NCRs and 1500mm for 6ft NCR. As shown below there is a tolerance of +/- 100mm.

If an Emergency version is used, ensure battery is connected before 1st use.




Wiring Instructions

Standard / Emergency




* Only used in -EM Variations

DALI




Switch Dim



Switched Live supplied from push to make retractive switch.

DALI (Switch Dim) & Emergency



For Switch Dim wiring, connect a permanent live to L1 and wire supply from retractive switch (push to make) to DALI / L. Also link between N and DALI / N.

IP65



Document Revision 3
29/01/2019