







Installation Instructions and Conditions of Use

- This product cannot be serviced; there are no serviceable parts inside and the product should not be opened unless instructed below to enable electrical connection / or mechanical fixing.
- The LEDs in the luminaire are not replaceable and the casing should not be opened. When the LEDs reach end of life the whole luminaire shall be replaced.
- Connect Battery before first use.



Wiring Instructions

Standard / Emergency

N Neutral

Earth

L1/Lp Permanent Live*

L2/Ls Switched Live

* Only used in -EM Variations

DALI

DALI / N

Neutral

Earth

Live

DALI / L

DALI (Switch Dim) & Emergency

N Neutral

Earth

L1/Lp Permanent Live*

L2/Ls Switched Live

* Only used in -EM Variations

Switch Dim

DALI / N

Neutral

Earth

Live

DALI / L

Switched Live supplied from push to make retractive switch.

For Switch Dim wiring, connect a permanent live to L1 and wire supply from retractive switch (push to make) to DALI / L. Also link between N and DALI / N.

